



## 48" CUPOLA WIND KIT INSTALLATION INSTRUCTIONS

- ① PREDRILL OVERHANG OF ROOF USING A  $\frac{3}{16}$ " DRILL BIT.
- ② REMOVE (2) CORNER CONNECTORS FROM A SINGLE ROOF PANEL BY SLIDING CONNECTORS DOWN.
- ③ REMOVE FASTENER FROM ROOF CAP THAT IS SECURING ROOF PANEL INTO PLACE AT TOP OF CUPOLA.
- ④ REMOVE SCREW ON EACH SIDE IN THE OVERHANG AT THE BOTTOM OF ROOF PANEL.
- ⑤ PULL TOP OF ROOF PANEL FROM UNDER ROOF CAP. IT MAY BE NECESSARY TO LOOSEN BUT NOT REMOVE THE OTHER 3 FASTENERS RETAINING ROOF CAP TO FREE ROOF PANEL FROM ROOF CAP.
- ⑥ REMOVE ROOF PANEL BY SLIDING IT Laterally FROM THE SIDE PANEL.
- ⑦ SPLICE WIND KIT PANELS TOGETHER USING 3.50" WIDE SPLICE PLATE AND SCREWS PROVIDED. SCREWS SHOULD BE STAGGERED 1" AND BE SPACED 6.50" APART.
- ⑧ SLIDE WIND KIT PANEL INTO OPENING CREATED BY REMOVED ROOF PANEL. SECURE WITH 1 SCREW (MIN) PER SIDE (3).
- ⑨ REASSEMBLE ROOF PANEL PER PAGE 2.
- ⑩ SCREW THROUGH OVERHANG OF ROOF PANEL WITH SCREWS PROVIDED. MAKE CERTAIN THAT SCREWS ARE HOLDING IN WIND KIT PANEL. BE CAUTIOUS, OVER TIGHTENING THE SCREWS MAY RESULT IN DISTORTION OF THE ROOF PANEL.

